Giraffy Co.

Golf Travel Bag



Your Giraffy Co. Golf Travel Bag is designed to protect and organize your golf clubs, shoes, and travel essentials during trips, tournaments, and everyday transport.

User Manual

Before First Use:

1. Remove all packaging materials from the travel bag.
2. Open the main zipper fully and check the inside compartment.
3. Make sure the ABS hard shell, zipper, wheels, lock, and handles are in good condition.
4. After placing your golf bag inside the travel bag, secure it with the internal buckle. Close the zipper completely, then fasten both exterior buckles to keep the bag firmly secured.
5. Use the inner space and outer pocket to organize shoes, accessories, towels, gloves, or travel items.
6. Use the included shoe covers before placing shoes into the side or front storage area.

Using the Shoe Covers

The included shoe covers are made from PU-coated water-resistant fabric. They help reduce dirt transfer from shoes to the inside of your golf travel bag.

Use them for:

- Golf shoes after playing on wet grass.
- Muddy or dusty shoes after a round.
- Regular shoes packed for travel.
- Keeping the side shoe compartment cleaner.

After use, wipe the shoe covers with a damp cloth and let them air dry completely before storing.

Care & Maintenance

- **Cleaning the Travel Bag:**
  Wipe the outer fabric with a soft damp cloth after travel or outdoor use. For dirt or mud, use mild soap with water and gently clean the affected area. Do not use bleach, harsh cleaners, alcohol-based sprays, or abrasive brushes.

  Allow the bag to air dry fully before storing. Do not place the bag in a dryer, near direct heat, or under strong sunlight for long periods.

- **Caring for the ABS Hard Shell:**
  The ABS hard shell is designed to help protect the top section of your golf clubs during travel. To keep it looking clean, wipe it with a microfiber cloth after use.

  Avoid dropping heavy items directly onto the hard shell. The shell is durable, but strong impact may cause scratches or surface marks.

- **Zipper & Lock Care:**
  Keep the zipper track clean and free from sand, mud, and debris. Open and close the zipper gently to maintain smooth movement.

  The TSA007 lock is designed for travel convenience. Please set and remember your combination before your first trip. Giraffy Co. is not responsible for forgotten lock codes.

- **Storage Tips:**
  Store the travel bag in a cool, dry place. Make sure the bag and shoe covers are fully dry before storage. Avoid placing heavy objects on top of the bag for long periods, as this may affect its shape.

Giraffy Co.

Our Commitment to You:

If any part is missing or defective, contact us via your Amazon order or at **service@giraffyco.com** for a free replacement.

Warranty Information:

This product is intended for personal golf travel and storage use only.

Scan to register your Golf Travel Bag and extend your warranty for free.

Scan to access to your manual in all available languages.

5.0 RATING ★★★★★

Share Your Experience:

Enjoying your new golf tavel bag?

Leaving a quick rating on Amazon makes our team smile and helps other golfers make their choice.